

# Human computer interface sa EOG-om

Luka Carić Petar Kovačević Elektrookulografija je tehnika detektovanja pokreta očiju na osnovu merenja potencijala između kornee (rožnjače) i retine(mrežnjače). Oko se može predstaviti električnim dipolom, gde je kornea (prednji deo) pozitivno, a retina (zadnji deo) negativno naelektrisana.






Signal

Signal

## Korišćena instrumentacija


- EOG pojačavač (instrumentacioni pojačavači sa filterom propusnikom opsega)
- Laboratorijsko napajanje (-5V do +5V)
- Arduino
- Pet površinskih elektroda (za jednokratnu upotrebu)
- Python aplikacija za očitavanje, kalibraciju i kontrolu miša

#### Postavka elektroda




Jedan kanal za pokrete gore-dole i jedan za pokrete levo-desno, referentna elektroda na čelu.

#### Analiza signala




Eyes moving 30° to the right



Eyes moving 15° to the left

## Klasifikacija pokreta oka



$$\text{classify(value)} \begin{cases} \text{value} \geq \text{Amplitude}_{\text{Threshold}} \cdot Tolerance \rightarrow High \\ \text{value} < \text{Amplitude}_{\text{Threshold}} \cdot Tolerance \rightarrow Low \end{cases}$$

## Kontrola miša pomoću EOG-a




Figure 16. Targets of eyes movements.





Figure 17. Eye movements.




# Hardver prototip




#### Novi zahtevi

- Manji šum
- Bolji kontakti
- Negativni napon napajanja



#### PCB 2D model

- 2 sloja
- SMD komponente
- Buck boost



#### 3D model

